


MDC050-050051 Series 50V, 5A Brushless Controller

User's Guide



ANAHEIM AUTOMATION

4985 E. Landon Drive Anaheim, CA 92807
e-mail: info@anaheimautomation.com

(714) 992-6990 fax: (714) 992-0471
website: www.anaheimautomation.com

MDC050-050051 Driver Features

- Open Loop Operation
- 1.5V to 4V External Voltage Speed Control
- 5V/10KHz External PWM Speed Control
- 2-Quadrant Operation
- Hall Sensor Feedback
- Short Circuit Protection
- Maximum Current Limit at 5.0 Amps (peak)
- Run/Stop, Freewheel and Direction Input
- TTL-CMOS Compatible Inputs
- Compact Size
- Screw Type Terminal Block

General Description

The MDC050-050051 driver is designed to drive DC Brushless motors at currents of up to 5A (peak) and 50V. The driver operates in the basic open loop configuration with either 60° or 120° DC Brushless motors. The driver is protected against over current (cycle-by-cycle), hall sensor error and under voltage. When an error occurs, a fault light is turned on to notify the user. Included on the driver is an internal potentiometer to control the maximum phase current allowed into the motor and an internal potentiometer to control the speed of the motor. An optional external voltage (1.5-4VDC) or external 5V/10KHz PWM signal can be used to control the speed as well. The direction of the motor can be preset by the direction control input. Other inputs to the drive include a run/stop and a motor freewheel input. The freewheel input overrides all other inputs into the driver.

Fault Protection

A cycle-by-cycle over current protection is provided when the motor current level exceeding the current limit set by adjusting R28 is produced. When the over current protection is activated, the controller shuts off the outputs to the motor. The maximum current set by R28 is a 5A per phase.

Suggested Power Supplies

Part #	Description
PSAM24V2.7A	DC Power Supply 24VDC at 2.7 Amps
PSAM48V1.3A	DC Power Supply 48VDC at 1.3 Amps

Specifications

Control Inputs: (TB1, Pins 1-3)

TTL-CMOS Compatible

Logic "0" = 0-0.8VDC

Logic "1" = OPEN

All Three inputs (run/stop, freewheel, and direction) are pulled up through 10k Ohm resistors.

Direction Control: (TB1, Pin 1)

Logic "1" (open) - Clockwise

Logic "0" - Counterclockwise

Freewheel: (TB1, Pin 2)

Logic "1" (open) - Motor is Enabled

Logic "0" - Motor is de-energized and will coast to a stop

Run/Stop: (TB1, Pin 3)

Logic "1" (open) - Motor will not run

Logic "0" - Motor will run and will accelerate according to speed setting

Vcontrol: (TB1, Pin 4)

To control the speed of the motor with an external DC voltage, a voltage from 1.5VDC-4VDC, must be applied with reference to AGND (TB1, Pin 5). Or, to control the speed of the motor with an external 5V/10KHz PWM signal, a duty cycle from 30% - 90%, must be applied with reference to AGND (TB1, Pin 5).

Care must be taken not to exceed 6V on this pin.

Output Current Rating:

5.0 amperes per phase maximum operating peak current, set by R28

2.5 amperes per phase maximum operating continuous current

Power Requirements: (TB2, Pins 4 and 5)

20VDC (min) - 50VDC (max)

Operating Temperature:

0° - 70°C

Heating Considerations:

The temperature of the driver transistors should never be allowed to rise above 70° Celsius. If necessary, air should be blown across the driver to maintain suitable temperatures.

Freewheel

The motor freewheel feature allows the de-energized of the motor phases. A high (open) input at this input causes the motor to run at the given speed, while a low at this input causes the motor to coast to a stop.

Motor Run/Stop

The motor run/stop feature allows the stopping of a motor by shorting out the bottom drives of the three phases. A low at this input allows the motor to run, while a high (open) input does not allow motor operation and if operating causes rapid deceleration.

Speed Adjust Setting

There are three ways to set the speed on this DC Brushless Motor Driver.

1. One is to use an external voltage by setting JP2 to position 2-3. If a voltage is used to control the speed of the motor, the 1.5V to 4V voltage can be tied on Vcontrol (TB1 - pin 4) with respect to AGND (TB1- Pin 5).
2. Another is to use external 5V/10Khz signal by setting JP2 to position 2-3. If a voltage is used to control the speed of the motor, the 30% to 90% duty cycle can be tied on Vcontrol (TB1- pin 4) with respect to AGND (TB1 - pin 5).
3. Another is to use the internal potentiometer, R18, by setting JP2 to position 1-2.

The maximum voltage amplitude that can be place on Vcontrol (TB1 - Pin 4) 6V. A voltage exceeding 6V will cause damage to the driver.

Terminal Block and Jumper Descriptions

Pin #	Description
1	Direction Freewheel
2	Freewheel
3	Run/Stop
4	Vcontrol
5	GND
6	Hall Power
7	Hall A
8	Hall B
9	Hall C
10	Hall GND

TB1: Control Inputs and Motor Halls


Pin #	Description
1	Direction Freewheel
2	Freewheel
3	Run/Stop
4	Vcontrol
5	GND

TB2: Power In and Motor Phases


Function	JP1	JP2
60° Hall Sensor Spacing	Open	---
120° Hall Sensor Spacing	1-2	---
Internal Speed Control (R13)	---	1-2
External Speed Control (Vcontrol)	---	2-3

JP1 and JP2: Functions and Settings

Typical Wiring Diagram




Dimensions



All units are in inches

Torque Speed Curves



COPYRIGHT

Copyright 2012 by Anaheim Automation. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual, or otherwise, without the prior written permission of Anaheim Automation, 4985 E Landon Drive, Anaheim, CA 92807.

DISCLAIMER

Though every effort has been made to supply complete and accurate information in this manual, the contents are subject to change without notice or obligation to inform the buyer. **In no event will Anaheim Automation be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation.**

Anaheim Automation's general policy does not recommend the use of its' products in life support applications wherein a failure or malfunction of the product may directly threaten life or injury. Per Anaheim Automation's Terms and Conditions, the user of Anaheim Automation products in life support applications assumes all risks of such use and indemnifies Anaheim Automation against all damages.

LIMITED WARRANTY

All Anaheim Automation products are warranted against defects in workmanship, materials and construction, when used under Normal Operating Conditions and when used in accordance with specifications. This warranty shall be in effect for a period of twelve months from the date of purchase or eighteen months from the date of manufacture, whichever comes first. **Warranty provisions may be voided if products are subjected to physical modifications, damage, abuse, or misuse.**

Anaheim Automation will repair or replace at its' option, any product which has been found to be defective and is within the warranty period, provided that the item is shipped freight prepaid, with previous authorization (RMA#) to Anaheim Automation's plant in Anaheim, California.

TECHNICAL SUPPORT

If you should require technical support or if you have problems using any of the equipment covered by this manual, please read the manual completely to see if it will answer the questions you have. If you need assistance beyond what this manual can provide, contact your Local Distributor where you purchased the unit, or contact the factory direct.

ANAHEIM AUTOMATION