

REVISIONS			
REV	DESCRIPTION	DATE	APPROVED

STEP 1

CLEAN MATING SURFACES FREE OF GREASE

STEP 2

LINE UP THE TWO SCREWS ON GEARBOX COUPLER WITH HOLES

STEP 3

IF THE MOTOR HAS A KEYWAY, REMOVE IT

STEP 4


FIT THE MOTOR IN THE GEARBOX

STEP 5

MOUNT MOTOR TO GEARBOX WITH SCREWS AND LOCK WASHERS PROVIDED

STEP 6

TIGHTEN COUPLER SCREWS AND PLACE PROVIDED CAPS OVER HOLES

 ANAHEIM AUTOMATION 910 EAST ORANGEFAIR LANE ANAHEIM, CA. 92801-1195		TITLE GBPH GEARBOX TO MOTOR MOUNTING INSTRUCTIONS	
<small>THIS DRAWING OR DOCUMENT AND THE INFORMATION SET FORTH HEREIN ARE THE PROPERTY OF ANAHEIM AUTOMATION AND SHALL NOT BE USED OR DISCLOSED EXCEPT IN ACCORDANCE WITH ITS WRITTEN PERMISSION.</small>		DATE 6-16-08	DRAWING NO. AA5203
REFERENCE DRAWINGS UNLESS OTHERWISE SPECIFIED: ALL DIMS XXX +/- .005 XXXX +/- .010 ANGLES +/- .5 DEGREES	MATERIAL FINISH 	SCALE 1/1	MODEL SHEET 1 OF 1
DRAWN T. RAINES APPROVED			